

M-AUDIO®

CODE25 Preset Editor

User Guide

English

Table of Contents

Introduction.....	4	Editing the Controls	10
Information & Support	4	Overview	10
Installation	4	Graphical User Interface.....	10
		Control Panel	11
Operation	5	Encoders.....	12
Getting Started	5	Faders.....	17
Managing Your Presets.....	6	Buttons	22
About Presets.....	6	MIDI	22
Loading & Retrieving Presets	7	Colors.....	33
Saving Presets.....	8	HID	34
Sending Presets.....	9	Pads	36
		MIDI	36
		Colors.....	47
		Keybed	48

Modulation & Pitch Wheels	50	Appendix	76
X-Y Pad	54	Velocity Curves	76
MIDI	54	Encoders.....	76
Note	59	Keybed	77
Sustain Pedal	60	Pads	78
Volume Pedal.....	68	X-Y Pad.....	79
Global Settings	73	Trademarks & Licenses.....	80
Software Menus	75		
File.....	75		
Help	75		

Introduction

The Code 25 Editor software gives you a visual and intuitive way to edit the various MIDI messages that your Code 25 keyboard's controls send to your computer.

Information & Support

For the latest information about this product (documentation, technical specifications, system requirements, compatibility information, etc.) and product registration, visit m-audio.com.

For additional product support, visit m-audio.com/support.

Installation

1. Double-click the **.exe** (Windows®) or **.pkg** (Mac® OS X®) installer file you downloaded.
2. Follow the on-screen instructions.

After the installation has completed, open the **Code 25 Preset Editor** by doing the following:


- **Windows:** Click the **Start Menu**, click **All Programs**, click the **M-Audio** folder, and then click **Code 25 Preset Editor**.
- **Mac OS X:** Double-click **Code 25 Preset Editor** in **Applications**.

Operation

Getting Started

To open the Code 25 Editor:

1. **Optional:** Connect your Code 25 keyboard to your computer using a standard USB cable. (If you are connecting your keyboard to a USB hub, make sure it is a powered hub.) You can still use the editor without connecting a Code 25, but you will not be able to send presets to it or retrieve presets from it.
2. Open the Code 25 Editor. The window will show a graphical representation of your Code 25 with all of its editable controls.



Managing Your Presets

About Presets

A preset is a preset file (**Code25**) containing all of the assignments you make in the Editor. This includes MIDI assignments, HID keystroke assignments, and color assignments. Using presets lets you maintain several different control configurations to use in different situations. For instance, you may use different presets with different kinds of software, or you may use some presets for production and others for performance.

Your Code 25 keyboard can store **12** presets at a time. You can store additional presets on your computer to load onto your Code 25 keyboard with this editor.

This chapter explains how to load presets into the editor ([Loading & Retrieving Presets](#)), save presets onto your computer ([Saving Presets](#)), and send presets to your connected Code 25 keyboard ([Sending Presets](#)).

Note: The current preset's name is shown in the upper-right corner of the window. This is the name that appears in your Code 25 keyboard's display when you load it. To change the name, click the field and enter a new name. Preset names can be 6 characters long and can include the following characters: **A–Z, 0–9, [] / \ - = _ ' .** and spaces.



Loading & Retrieving Presets

To edit a preset, you first have to load it into the Code 25 Editor. You can **load** a preset from your computer or **retrieve** a preset from your connected Code 25 keyboard.

Note: The current preset's name is shown in the upper-right corner of the window. This is the name that appears in your Code 25 keyboard's display when you load it. To change the name, click the field and enter a new name. Preset names can be 6 characters long and can include the following characters: **A–Z, 0–9, [] / \ - = _ ' .** and spaces.



To load a preset from your computer, do one of the following:

- Click **File** and then click **Load Preset**.
- Press **Ctrl+O** (Windows) or **Control+O** (Mac OS X).

After that, locate the desired preset file (**.Code25**), and click **Open**.

To retrieve a preset from your connected Code 25:

1. Click **File** and then click **Retrieve Preset**. Alternatively, press **Ctrl+Shift+R** (Windows) or **Control+Shift+R** (Mac OS X).
2. In the window that appears, click the drop-down menu to select the desired preset number (**Preset 1–12**) or the current settings of your Code 25 (**RAM**).
3. Click **Get** to confirm your choice, or click the **X** in the upper-right corner to close the window and cancel the operation.

Important: Editing this preset will not affect the preset stored on your Code 25. See [Sending Presets](#) below to learn how to send the edited preset to your Code 25.

Saving Presets

Saving a preset on your computer lets you edit it or send it to your Code 25 in the future. All MIDI assignments that you see in the editor will be saved in the preset.

Note: The current preset's name is shown in the upper-right corner of the window. This is the name that appears in your Code 25 keyboard's display when you load it. To change the name, click the field and enter a new name. Preset names can be 6 characters long and can include the following characters: **A–Z, 0–9, [] / \ - = _ ' .** and spaces.



To save the preset, do one of the following:

- Click **File** and then click **Save Preset**.
- Press **Ctrl+S** (Windows) or **Control+S** (Mac OS X).

If this is the first time you are saving the preset, select the desired location, enter a file name, and click **Save**. The preset will be saved as a **.Code25** file.

Sending Presets

Sending a preset to your connected Code 25 lets you transfer the preset from the editor to your Code 25 keyboard's internal memory. All MIDI assignments that you see in the editor will be sent to your Code 25.

Note: The current preset's name is shown in the upper-right corner of the window. This is the name that appears in your Code 25 keyboard's display when you load it. To change the name, click the field and enter a new name. Preset names can be 6 characters long and can include the following characters: **A–Z, 0–9, [] / \ - = _ ' .** and spaces.




To send a preset to your connected Code 25:

1. Click **File** and then click **Send Preset**. Alternatively, press **Ctrl+Shift+S** (Windows) or **Control+Shift+S** (Mac OS X).
2. In the window that appears, click the drop-down menu to select the desired preset number (**Preset 1–12**) or the current settings of your Code 25 (**RAM**).
3. Click **Send** to confirm your choice, or click the **X** in the upper-right corner to close the window and cancel the operation. (Sending the preset will overwrite that preset number on your Code 25.)

Editing the Controls

Overview

Graphical User Interface



To edit the parameters for a type of control on your Code 25, click the desired control in the graphic of the Code 25 in the software window.

Click one of the types of controls to jump to that section of this User Guide.

[*Encoders*](#)

[*Pads*](#)

[*X-Y Pad*](#)

[*Faders*](#)

[*Keybed*](#)

[*Sustain Pedal*](#)

[*Buttons*](#)

[*Modulation & Pitch Wheels*](#)

[*Volume Pedal*](#)

Control Panel

BUTTON 1

MIDI | COLORS | HID

NOTE | MMC | PROGRAM | PROGRAM CYCLE | PROGRAM IN/DEC | CC ABSOLUTE | CC CYCLE | CC IN/DEC | RPN/NRPN | OTHER

CC: 0 Bank Select FIRST 0

CHAN: Global VALUE 3 0

TYPE: 4 Values VALUE 4 0

LAST 0

BANK 1

The bottom part of the window is the **control panel**, which shows the available and current modes and parameters of the selected Code 25 control. Its name will appear in the upper-left corner of the control panel, and it will be highlighted in the graphical user interface above it, as well.

To select a button, click it.

MIDI | NOTE

CC ABSOLUTE | CC RELATIVE | RPN/NRPN | OTHER

To use a drop-down menu, click it to reveal the menu options, and then click an option to select it.

TYPE: RPN Coarse

MSB: RPN Coarse

LSB: RPN Fine

CHAN: NRPN Coarse

NRPN Fine

To use a value field, do any of the following:

- Click it and enter a number (0–127).
- Click the up (▲) or down (▼) arrows next to the field.
- Click it and then use your computer's up (▲) or down (▼) keys.

CC: 0 Bank Select


MIN: 0

To use a checkbox, click it to check (enable) or uncheck (disable) it. (Doing so may reveal or hide additional parameters that you can set.)

LATCH ☒

ON/OFF ☐

Encoders



Click one of the encoders (**E1–E4**) to set the MIDI assignments for the corresponding **encoder** on your Code 25. Click one of the **Bank** buttons (**1–4**) at the top of the window to select another bank of encoders. You can assign the parameters for the encoders in MIDI Mode only.

Mode: Click one of the 4 buttons to select the corresponding mode for the encoder. The parameters below will depend on your selection.

- **CC Absolute:** The encoder will send CC messages based on its current physical position.
- **CC Relative:** The encoder will send CC messages to increment or decrement the current value.
- **RPN/NRPN:** The encoder will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The encoder will send a message for another type of command.

ENCODER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/INRPN

OTHER

CC	40	Balance LSB	↑	↓
MIN	0		↑	↓
MAX	127		↑	↓
CHAN	Global		↑	↓

When set to **CC Absolute**, these are the available parameters:

- **CC:** The encoder will send its MIDI messages using this CC number.
- **Min:** The encoder's minimum position will correspond with this value. You can reverse the encoder's polarity by making this value larger than the **Max** value.
- **Max:** The encoder's maximum position will correspond with this value. You can reverse the encoder's polarity by making this value smaller than the **Min** value.
- **Chan:** The encoder will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

ENCODER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Up (Type 1)

CC

40 Balance LSB

CHAN

Global

When set to **CC Relative**, these are the available parameters:

- **Type:** The encoder will increment or decrement the CC's current value, depending on this setting. Select one of these options:
 - **Up (Type 1) or Up (Type 2):** Turning the encoder clockwise increments the value. Turning it counter-clockwise decrements the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
 - **Down (Type 1) or Down (Type 2):** Turning the encoder clockwise decrements the value. Turning it counter-clockwise increments the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
- **CC:** The encoder will send its MIDI messages using this CC number.
- **Chan:** The encoder will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

ENCODER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

RPN Coarse

▼

MSB

0

▼

LSB

0

▼

CHAN

Global

▼

When set to **RPN/NRPN**, these are the available parameters:

- Type:** The encoder will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - RPN Coarse** or **RPN Fine:** Turning the encoder adjusts the RPN coarsely or finely, respectively.
 - NRPN Coarse** or **NRPN Fine:** Turning the encoder adjusts the NRPN coarsely or finely, respectively.
- MSB:** The encoder will send this Most Significant Byte value when you turn it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- LSB:** The encoder will send this Least Significant Byte value when you turn it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- Chan:** The encoder will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

ENCODER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN


OTHER

TYPE	Pitch Bend Sensitivity(RPN)	▼
MIN	0	▲▼
MAX	0	▲▼
CHAN	Global	▼

When set to **Other**, these are the available parameters:

- Type:** The encoder will adjust this parameter when you turn it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), or **Pitch Bend**.
- Min:** The encoder's minimum position will correspond with this value. Click it and enter a number (**0–127**). You can reverse the encoder's polarity by making this value larger than the **Max** value.
- Max:** The encoder's maximum position will correspond with this value. Click it and enter a number (**0–127**). You can reverse the encoder's polarity by making this value smaller than the **Min** value.
- Chan:** The encoder will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Faders



Click one of the faders (**F1–F5**) to set the MIDI assignments for the corresponding **fader** on your Code 25. Click one of the **Bank** buttons (**1–4**) at the top of the window to select another bank of faders. You can assign the parameters for the fader in MIDI Mode only.

Mode: Click one of the 4 buttons to select the corresponding mode for the fader. The parameters below will depend on your selection.

- **CC Absolute:** The fader will send CC messages based on its current physical position.
- **CC Relative:** The fader will send CC messages to increment or decrement the current value.
- **RPN/NRPN:** The fader will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The fader will send a message for another type of command.

FADER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

CC

0 Bank Select

↑

↓

MIN

0

↑

↓

MAX

127

↑

↓

CHAN

Global

↓

When set to **CC Absolute**, these are the available parameters:

- **CC:** The fader will send its MIDI messages using this CC number.
- **Min:** The fader's minimum position will correspond with this value. You can reverse the fader's polarity by making this value larger than the **Max** value.
- **Max:** The fader's maximum position will correspond with this value. You can reverse the fader's polarity by making this value smaller than the **Min** value.
- **Chan:** The fader will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

FADER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Up (Type 1)

▼

CC

0 Bank Select

▲▼

CHAN

Global

▼

When set to **CC Relative**, these are the available parameters:

- Type:** The fader will increment or decrement the CC's current value, depending on this setting. Select one of these options:
 - Up (Type 1) or Up (Type 2):** Moving the fader up increments the value. Moving it down decrements the value. If your software does not respond to the (**Type 1**) setting, use the (**Type 2**) setting—or vice versa.
 - Down (Type 1) or Down (Type 2):** Moving the fader up decrements the value. Moving it down increments the value. If your software does not respond to the (**Type 1**) setting, use the (**Type 2**) setting—or vice versa.
- CC:** The fader will send its MIDI messages using this CC number.
- Chan:** The fader will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

FADER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

RPN Coarse

▼

MSB

1

▲▼

LSB

127

▲▼

CHAN

Global

▼

When set to **RPN/NRPN**, these are the available parameters:

- Type:** The fader will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - RPN Coarse** or **RPN Fine:** Moving the fader adjusts the RPN coarsely or finely, respectively.
 - NRPN Coarse** or **NRPN Fine:** Moving the fader adjusts the NRPN coarsely or finely, respectively.
- MSB:** The fader will send this Most Significant Byte value when you move it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- LSB:** The fader will send this Least Significant Byte value when you move it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- Chan:** The fader will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

FADER 1

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Pitch Bend Sensitivity(RPN)

MIN

0

MAX

127

CHAN

Global

When set to **Other**, these are the available parameters:


- Type:** The fader will adjust this parameter when you move it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), or **Pitch Bend**.
- Min:** The fader's minimum position will correspond with this value. You can reverse the fader's polarity by making this value larger than the **Max** value.
- Max:** The fader's maximum position will correspond with this value. You can reverse the fader's polarity by making this value smaller than the **Min** value.
- Chan:** The fader will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Buttons



Click one of the buttons (**B1–B5**) to set the MIDI assignments for the corresponding **button** on your Code 25. Click one of the **Bank** buttons (**1–4**) at the top of the window to select another bank of buttons. You can assign the parameters for the buttons in *MIDI Mode* or *HID Mode* as well as the buttons' *Colors*.

MIDI



Mode: Click this menu and select one of the following options. The parameters below will depend on your selection.

- **Note:** The button will send MIDI note messages.
- **MMC:** The button will send MMC (MIDI Machine Control) messages. MMC is a transport control protocol that is used to remotely control some recording hardware and DAWs.
- **Program:** The button will send a combined program number, Bank LSB, and Bank MSB number. This can be useful for selecting a preset from a specific bank of a virtual instrument or synthesizer (the instrument or synthesizer must support these messages).
- **Program Cycle:** The button will cycle through 2, 3, or 4 program numbers each time you press it.

- **Program Inc/Dec:** The button will increment/decrement the program number by **1** each time you press it. After it reaches its highest or lowest program, it will “wrap around” and start again at its lowest or highest program, respectively. In other words, pressing the button causes the value to cycle through its entire range by increments of 1.
- **CC Absolute:** The button will send MIDI CC messages with a “pressed” value and a “released” value.
- **CC Cycle:** The button will cycle through 2, 3, or 4 MIDI CC values each time you press it.
- **CC Inc/Dec:** The button will increment/decrement a MIDI CC value by **1** each time you press it. After it reaches its highest or lowest value, it will “wrap around” and start again at its lowest or highest value, respectively. In other words, pressing the button causes the value to cycle through its entire range by increments of 1.
- **RPN/NRPN:** The button will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The button will send a message for another type of command.

BUTTON 1

MIDI	COLORS	HID							
NOTE	MMC	PROGRAM	PROGRAM CYCLE	PROGRAM INC/DEC	CC ABSOLUTE	CC CYCLE	CC INC/DEC	RPN/NRPN	OTHER

NOTE 24 C(1) LATCH ✓

CHAN Global ↕

ON 127 ↕

OFF 0 ↕

BANK 1

When set to **Note**, these are the available parameters:

- **Note:** The button will send this MIDI note number when you press it.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Latch:** When Latch is enabled, the button will send one value when pressed and a different value when pressed a second time, alternating between the two values with each press (“latching” or “toggle” behavior). When Latch is disabled, the button will send one value when pressed and one value when released (“momentary” behavior).
- **On:** The button will send the MIDI note number with this velocity when you press it to turn it on.
- **Off:** The button will send the MIDI note number with this velocity when you press it to turn it off. This value will usually be **0** (to turn the note off).

BUTTON 1

MDI COLORS HID

NOTE **MMC** PROGRAM PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC RPN/RRPN OTHER

MMC Stop ▼

CHAN Global ▼

BANK 1

When set to **MMC**, these are the available parameters:

- **MMC:** The button will send this MMC message when you press it. Select **Stop**, **Play**, **Deferred Play**, **Fast-Forward**, **Rewind**, **Record Strobe** (Punch In), **Record Exit** (Punch Out), **Record Pause**, **Pause**, **Eject**, **Chase**, or **MMC Reset**.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

MDI COLORS HID

NOTE MMC **PROGRAM** PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC RPN/RRPN OTHER

PROGRAM 1 ⬆️ ⬇️ ⬆️

MSB 1 ⬆️ ⬇️ ⬆️

LSB 127 ⬆️ ⬇️ ⬆️

CHAN Global ⬇️

BANK 1

When set to **Program**, these are the available parameters:

- **Program:** The button will send this program number when you press it.
- **MSB:** The button will send this Bank MSB (Most Significant Byte) number when you press it.
- **LSB:** The button will send this Bank LSB (Least Significant Byte) number when you press it.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

MIDI

COLORS

HID

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN1/RPN

OTHER

CHAN

Global

▼

FIRST

1

↕

TYPE

4 Values

▼

VALUE 2

2

↕

VALUE 3

3

↕

LAST

4

↕

BANK 1

When set to **Program Cycle**, these are the available parameters:

- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Type:** The button will cycle through this many program numbers (one at a time) when you press it: **2 Values**, **3 Values**, or **4 Values**.
- **First & Last:** The button will send these program numbers when you press it, one at a time, cycling through them with each press.

If **Type** is set to **3 Values** or **4 Values**, use the **Value 2** and **Value 3** fields to select additional program numbers.

BUTTON 1

MIDI

COLORS

HID

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN1/RPN

OTHER

TYPE

Increment

▼

MIN

0

↕

MAX

62

↕

CHAN

Global

▼

BANK 1

When set to **Program Inc/Dec**, these are the available parameters:

- **Type:** The button will send the next (**Increment**) or previous (**Decrement**) program number in the range of programs when you press it.
- **Min:** The lowest program in the range of programs will correspond with this value.
- **Max:** The highest program in the range of programs will correspond with this value.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

MIDI

COLORS

HID

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN1/RPN

OTHER

CC

DOWN

UP

CHAN

0 Bank Select

127

0

Global

↕

↕

↕

↕

BANK 1

When set to **CC Absolute**, these are the available parameters:

- **CC:** The button will send its MIDI messages using this CC number.
- **Down:** The button will send the MIDI CC number with this value when you press it.
- **Up:** The button will send the MIDI CC number with this value when you release it.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

	MIDI	COLORS	HID
	NOTE	MMC	PROGRAM
CC	0 Bank Select		FIRST
CHAN	Global		VALUE 2
TYPE	4 Values		VALUE 3
			LAST

PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC RPN/RPN PROGRAM OTHER

BANK 1

When set to **CC Cycle**, these are the available parameters:

- **CC:** The button will send its MIDI messages using this CC number.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Type:** The button will cycle through this many values with the CC number (one at a time) when you press it: **2 Values**, **3 Values**, or **4 Values**.
- **First & Last:** The button will send these values with the CC number when you press it, one at a time, cycling through them with each press.

If **Type** is set to **3 Values** or **4 Values**, use the **Value 2** and **Value 3** fields to select additional values.

BUTTON 1

MIDI **COLORS** HID

NOTE MMC PROGRAM PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE **CC INC/DEC** RPN/RPN OTHER

TYPE Increment CHAN Global

CC 0 Bank Select

MIN 0

MAX 64

BANK 1

When set to **CC Inc/Dec**, these are the available parameters:

- **Type:** The button will send the next (**Increment**) or previous (**Decrement**) value number in the range of values when you press it.
- **CC:** The button will send its MIDI messages using this CC number.
- **Min:** The lowest value in the range of values will correspond with this value.
- **Max:** The highest value in the range of values will correspond with this value.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

MIDI COLORS HID

NOTE MMC PROGRAM PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC **RPN/NRPN** OTHER

TYPE RPN Coarse CHAN Global

MSB 0 < >

LSB 93 < >

VALUE 0 < >

BANK 1

When set to **RPN/NRPN**, these are the available parameters:

- **Type:** The button will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - **RPN Coarse** or **RPN Fine:** Pressing the button adjusts the RPN coarsely or finely, respectively.
 - **NRPN Coarse** or **NRPN Fine:** Pressing the button adjusts the NRPN coarsely or finely, respectively.
- **MSB:** The button will send this Most Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- **LSB:** The button will send this Least Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- **Value:** The button will send this value with the RPN or NRPN when you press it.
- **Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

BUTTON 1

MIDI

COLORS

HID

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN/RPN

OTHER

TYPE

VALUE

CHAN

Pitch Bend Sensitivity(RPN)

127

Global

BANK 1

When set to **Other**, these are the available parameters:

- Type:** The button will send a value for this parameter when you press it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), **Pitch Bend**, **Reverb Type** (SysEx), **Reverb Time** (SysEx), or **Chorus Type** (SysEx).
- Value:** The button will send this value for the parameter when you press it.
- Chan:** The button will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Colors

BUTTON 1

MIDI **COLORS** HID

COLOR 1 Magenta ▾ HID COLOR Off ▾

COLOR 2 Blue ▾

COLOR 3 White ▾

COLOR 4 Red ▾

Each button can have a set of colors assigned to it, making it easier to distinguish between their different functions, notes, etc. Each button can use up to 4 colors, depending on its function.


Use the 5 **Color** drop-down menus to select the color for each button state. The fifth drop-down menu corresponds to its color in HID Mode. (All 4 drop-down menus will be shown even if the button uses only 2 or 3 states.)

Tip: Press **Shift** and click a **button** to cycle through its colors.

0	Off
1	Green
2	Cyan
3	Blue

4	Magenta
5	Red
6	Yellow
7	White

HID



The HID (human interface device) protocol lets devices send standard computer keyboard keystrokes. USB game controllers are an example of this, acting as an alternative to your computer's keyboard. Your Code 25 keyboard's assignable **buttons** can also use the HID protocol, letting you configure certain buttons to send your most-often used keystrokes to your software (for example, **Control** + **C** to copy).

Use the **Key** drop-down menu to select the keystroke the button will send:

Off	Up ↑	`	-	Page Up
0–9	Down ↓	[	+	Delete
A–Z	Left ←	]	*	End
Space	Right →	\	=	Page Down
F1–F12	Tab	/	Esc	0–9 (numeric keypad)
Backspace	,	`	Insert	
Enter	.	;	Home	

Use the **Mod Key** drop-down menu to select the modifier the button will send:

	<u>Windows Modifiers</u>	<u>Mac OS X Modifiers</u>
Off	Shift	Shift
	Control	Control
	Window	Control
	Alt	Option
	Shift+Control	Shift+Control
	Shift+Window	Shift+Option
	Shift+Alt	Shift+Control
	Control+Window	Control+Control
	Control+Alt	Control+Option
	Window+Alt	Control+Option
	Shift+Control+Window	Shift+Control+Control
	Shift+Control+Alt	Shift+Control+Option
	Shift+Window+Alt	Shift+Option+Control
	Control+Window+Alt	Control+Control+Option

Pads

Click one of the pads (**P1–P16**) to set the MIDI assignments for the corresponding **pad** on your Code 25. You can assign the parameters for the pads in **MIDI Mode** as well as the pads' **Colors**.



MIDI

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN1/RPN

OTHER

Mode: Click this menu and select one of the following options. The parameters below will depend on your selection.

- **Note:** The pad will send MIDI note messages.
- **MMC:** The pad will send MMC (MIDI Machine Control) messages. MMC is a transport control protocol that is used to remotely control some recording hardware and DAWs.
- **Program:** The pad will send a combined program number, Bank LSB, and Bank MSB number. This can be useful for selecting a preset from a specific bank of a virtual instrument or synthesizer (the instrument or synthesizer must support these messages).
- **Program Cycle:** The pad will cycle through 2, 3, or 4 program numbers each time you press it.

- **Program Inc/Dec:** The pad will increment/decrement the program number by **1** each time you press it. After it reaches its highest or lowest program, it will “wrap around” and start again at its lowest or highest program, respectively. In other words, pressing the pad causes the value to cycle through its entire range by increments of 1.
- **CC Absolute:** The pad will send MIDI CC messages with a “pressed” value and a “released” value.
- **CC Cycle:** The pad will cycle through 2, 3, or 4 MIDI CC values each time you press it.
- **CC Inc/Dec:** The pad will increment/decrement a MIDI CC value by **1** each time you press it. After it reaches its highest or lowest value, it will “wrap around” and start again at its lowest or highest value, respectively. In other words, pressing the pad causes the value to cycle through its entire range by increments of 1.
- **RPN/NRPN:** The pad will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The pad will send a message for another type of command.

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM IN/DEC

CC ABSOLUTE

CC CYCLE

CC IN/DEC

RPN1/RPN

OTHER

NOTE 36 C(2) ↕ LATCH ☒

CHAN Global ↕

ON 127 ↕

OFF 0 ↕

When set to **Note**, these are the available parameters:

- **Note:** The pad will send this MIDI note number when you press it.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Latch:** When Latch is enabled, the pad will send one value when pressed and a different value when pressed a second time, alternating between the two values with each press (“latching” or “toggle” behavior). When Latch is disabled, the pads will send one value when pressed and one value when released (“momentary” behavior).
- **On** (available if **Latch** is enabled): The pad will send the MIDI note number with this velocity when you press it to turn it on.
- **Off** (available if **Latch** is enabled): The pad will send the MIDI note number with this velocity when you press it to turn it off. This value will usually be **0** (to turn the note off).

PAD 1

MIDI COLOR

NOTE MMC PROGRAM PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC RPN/RRPN OTHER

MMC Stop

CHAN GLOBAL

When set to **MMC**, these are the available parameters:

- **MMC:** The pad will send this MMC message when you press it. Select **Stop**, **Play**, **Deferred Play**, **Fast-Forward**, **Rewind**, **Record Strobe** (Punch In), **Record Exit** (Punch Out), **Record Pause**, **Pause**, **Eject**, **Chase**, or **MMC Reset**.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

MIDI COLOR

NOTE MMC PROGRAM PROGRAM CYCLE PROGRAM INC/DEC CC ABSOLUTE CC CYCLE CC INC/DEC RPN/RRPN OTHER

PROGRAM 0

MSB 0

LSB 0

CHAN GLOBAL

When set to **Program**, these are the available parameters:

- **Program:** The pad will send this program number when you press it.
- **MSB:** The pad will send this Bank MSB (Most Significant Byte) number when you press it.
- **LSB:** The pad will send this Bank LSB (Least Significant Byte) number when you press it.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

	MIDI	COLOR									
	NOTE	MMC	PROGRAM	PROGRAM CYCLE	PROGRAM INC/DEC	CC ABSOLUTE	CC CYCLE	CC INC/DEC	RPN/IRPN	OTHER	
CHAN	Global		FIRST	0							
TYPE	4 Values		VALUE 2	1							
			VALUE 3	2							
			LAST	3							

When set to **Program Cycle**, these are the available parameters:

- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Type:** The pad will cycle through this many program numbers (one at a time) when you press it: **2 Values**, **3 Values**, or **4 Values**.
- **First & Last:** The pad will send these program numbers when you press it, one at a time, cycling through them with each press.

If **Type** is set to **3 Values** or **4 Values**, use the **Value 2** and **Value 3** fields to select additional program numbers.

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN1/RPN

OTHER

TYPE

MIN

MAX

CHAN

Increment

0

40

Global

When set to **Program Inc/Dec**, these are the available parameters:

- **Type:** The pad will send the next (**Increment**) or previous (**Decrement**) program number in the range of programs when you press it.
- **Min:** The lowest program in the range of programs will correspond with this value.
- **Max:** The highest program in the range of programs will correspond with this value.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM IN/DEC

CC ABSOLUTE

CC CYCLE

CC IN/DEC

RP/NR/PN

OTHER

CC

DOWN

UP

CHAN

0 Bank Select

127

0

Global

↕

↕

↕

▼

When set to **CC Absolute**, these are the available parameters:

- **CC:** The pad will send its MIDI messages using this CC number.
- **Down:** The pad will send the MIDI CC number with this value when you press it.
- **Up:** The pad will send the MIDI CC number with this value when you release it.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

	MIDI	COLOR								
	NOTE	MMC	PROGRAM	PROGRAM CYCLE	PROGRAM INC/DEC	CC ABSOLUTE	CC CYCLE	CC INC/DEC	RPN1/RPN	OTHER
CC	0 Bank Select		FIRST	0						
CHAN	Global		VALUE 2	1						
TYPE	4 Values		VALUE 3	2						
			LAST	3						

When set to **CC Cycle**, these are the available parameters:

- **CC:** The pad will send its MIDI messages using this CC number.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Type:** The pad will cycle through this many values with the CC number (one at a time) when you press it: **2 Values**, **3 Values**, or **4 Values**.
- **First & Last:** The pad will send these values with the CC number when you press it, one at a time, cycling through them with each press.

If **Type** is set to **3 Values** or **4 Values**, use the **Value 2** and **Value 3** fields to select additional values.

PAD 1

	MIDI	COLOR	
	NOTE	MMC	PROGRAM
			PROGRAM CYCLE
			PROGRAM INC/DEC
			CC ABSOLUTE
			CC CYCLE
			CC INC/DEC
			RPN/RPN
			OTHER
TYPE	Increment		CHAN
CC	0 Bank Select		Global
MIN	64		
MAX	127		

When set to **CC Inc/Dec**, these are the available parameters:

- **Type:** The pad will send the next (**Increment**) or previous (**Decrement**) value number in the range of values when you press it.
- **CC:** The pad will send its MIDI messages using this CC number.
- **Min:** The lowest value in the range of values will correspond with this value.
- **Max:** The highest value in the range of values will correspond with this value.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN/MRPI

OTHER

TYPE

MSB

LSB

VALUE

RPN Coarse

1

127

60

CHAN

Global

When set to **RPN/NRPN**, these are the available parameters:

- **Type:** The pad will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - **RPN Coarse** or **RPN Fine:** Pressing the pad adjusts the RPN coarsely or finely, respectively.
 - **NRPN Coarse** or **NRPN Fine:** Pressing the pad adjusts the NRPN coarsely or finely, respectively.
- **MSB:** The pad will send this Most Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- **LSB:** The pad will send this Least Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- **Value:** The pad will send this value with the RPN or NRPN when you press it.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

PAD 1

MIDI

COLOR

NOTE

MMC

PROGRAM

PROGRAM CYCLE

PROGRAM INC/DEC

CC ABSOLUTE

CC CYCLE

CC INC/DEC

RPN/VRPN

OTHER

TYPE

VALUE

CHAN

Pitch Bend Sensitivity(RPN)


127

Global

When set to **Other**, these are the available parameters:

- **Type:** The pad will send a value for this parameter when you press it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), **Pitch Bend**, **Reverb Type** (SysEx), **Reverb Time** (SysEx), or **Chorus Type** (SysEx).
- **Value:** The pad will send this value for the parameter when you press it.
- **Chan:** The pad will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Colors



Each pad can have a set of colors assigned to it, making it easier to distinguish between their different functions, notes, etc. Each pad can use up to 4 colors, depending on its function.


Use the 4 **Color** drop-down menus to select the color for each pad state. (All 4 drop-down menus will be shown even if the pad uses only 2 or 3 states.)

Tip: Press **Shift** and click a **pad** to cycle through its colors.

0	Off
1	Chartreuse
2	Green
3	Aquamarine
4	Cyan
5	Azure
6	Blue

7	Violet
8	Magenta
9	Rose
10	Red
11	Orange
12	Yellow
13	White

Keybed



The **keybed** (the piano keys) on your Code 25 can be divided into 1–4 “zones.” When zones are active (when the **Zone** button and one or more **Zone 1–4** buttons are lit), each zone can send its controls’ MIDI messages over its own MIDI channel. You can assign the parameters for the keybed/zones in MIDI Mode only.

Tip: This feature is great for dividing your Code keyboard between different virtual instruments or synthesizers. For example, you can create two zones, each using a different MIDI channel, and play and control two virtual instruments simultaneously—one with each half of the keys.

Click one of the **Zone 1–4** piano keys to set the MIDI assignments for the corresponding zone on your Code 25. All 4 zones have the same parameters, which you can set independently.

ZONE 1				
	MIDI			
ON/OFF	☐			
FIRST	0	C (2)	PROGRAM	0
LAST	24	C (4)	MSB	0
OCTAVE	0		LSB	0
TRANPOSE	0		CHAN	Global

These are the available parameters:

- **On/Off:** When this box is checked, the zone on your Code 25 keyboard will be active. When this box is unchecked, the zone on your Code 25 keyboard will be inactive.
- **First:** The zone’s lowest key will correspond with this note.
- **Last:** The zone’s highest key will correspond with this note.

- **Octave:** The zone's keys will send their notes using this octave shift (from their original position on the keyboard).

Note: The zone octave and transposition are independent from the keyboard's overall octave and transposition, but all of these affect the note a key sends out.

- **Transpose:** The zone's keys will send their notes using this transposition (from their original position on the keyboard).

Note: The zone octave and transposition are independent from the keyboard's overall octave and transposition, but all of these affect the note a key sends out.

- **Program:** The zone will send this program number when you press a key in it.
- **MSB:** The zone will send this Bank MSB (Most Significant Byte) number when you press a key in it.
- **LSB:** The zone will send this Bank LSB (Least Significant Byte) number when you press a key in it.
- **Chan:** The zone will send its messages over this channel. Select the global channel (**Global**) or a specific channel (**Channel 1–16**).

Note: Any other controls whose **Chan** settings are set to this zone will send their messages using this channel, as well.

Modulation & Pitch Wheels

Click the **modulation wheel** (the left wheel) or the **pitch-bend wheel** (the right wheel) to set the MIDI assignments for the corresponding **wheel** on your Code 25. You can assign the parameters for the modulation wheel and pitch wheel in MIDI Mode only.



P. WHEEL

MIDI

CC ABSOLUTE

RPN/NRPN

OTHER

Mode: Click one of the 4 buttons to select the corresponding mode for the wheel. The parameters below will depend on your selection.

- **CC Absolute:** The wheel will send CC messages based on its current physical position.
- **RPN/NRPN:** The wheel will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The wheel will send a message for another type of command.

P. WHEEL

MIDI

CC ABSOLUTE

RPN/NRPN

OTHER

CC

14 Controller 14

⬆

MIN

0

⬆

MAX

127

⬆

CHAN

Global

⬇

When set to **CC Absolute**, these are the available parameters:

- **CC:** The wheel will send its MIDI messages using this CC number.
- **Min:** The wheel's minimum position will correspond with this value. You can reverse the wheel's polarity by making this value larger than the **Max** value.
- **Max:** The wheel's maximum position will correspond with this value. You can reverse the wheel's polarity by making this value smaller than the **Min** value.
- **Chan:** The wheel will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

P. WHEEL	
	MIDI CC ABSOLUTE RPN/NRPN OTHER
TYPE	RPN Coarse ▼
MSB	30 ▼
LSB	60 ▼
CHAN	Global ▼

When set to **RPN/NRPN**, these are the available parameters:

- **Type:** The wheel will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - **RPN Coarse** or **RPN Fine:** Moving the wheel adjusts the RPN coarsely or finely, respectively.
 - **NRPN Coarse** or **NRPN Fine:** Moving the wheel adjusts the NRPN coarsely or finely, respectively.
- **MSB:** The wheel will send this Most Significant Byte value when you move it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- **LSB:** The wheel will send this Least Significant Byte value when you move it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- **Chan:** The wheel will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

P. WHEEL	
	MIDI CC ABSOLUTE RPN/NRPN OTHER
TYPE	Pitch Bend Sensitivity(RPN) ▼
MIN	0 ▲▼
MAX	127 ▲▼
CHAN	Global ▼

When set to **Other**, these are the available parameters:


- **Type:** The wheel will adjust this parameter when you move it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), or **Pitch Bend**.
- **Min:** The wheel's minimum position will correspond with this value. You can reverse the wheel's polarity by making this value larger than the **Max** value.
- **Max:** The wheel's maximum position will correspond with this value. You can reverse the wheel's polarity by making this value smaller than the **Min** value.
- **Chan:** The wheel will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

X-Y Pad

Click **X** or **Y** in the X-Y pad to set the MIDI assignments for the corresponding axis of the **X-Y pad** on your Code 25. You can assign the parameters for the X-Y pad in **MIDI Mode** and **Note Mode**.



MIDI



Mode: Click one of the 4 buttons to select the corresponding mode for the axis. The parameters below will depend on your selection.

- **CC Absolute:** The axis will send CC messages based on the current physical position of your finger on it.
- **CC Relative:** The axis will send CC messages to increment or decrement the current value.
- **RPN/NRPN:** The axis will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The axis will send a message for another type of command.

X-AXIS	
	MIDI NOTE
	CC ABSOLUTE CC RELATIVE RPN/NRPN OTHER
CC	1 Modulation
MIN	0
MAX	127
CHAN	Global

When set to **CC Absolute**, these are the available parameters:

- **CC:** The axis will send its MIDI messages using this CC number.
- **Min:** The axis's minimum position will correspond with this value. You can reverse the axis's polarity by making this value larger than the **Max** value.
- **Max:** The axis's maximum position will correspond with this value. You can reverse the axis's polarity by making this value smaller than the **Min** value.
- **Chan:** The axis will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

X-AXIS

MIDI

NOTE

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Up (Type 1)

▼

CC

1

Modulation

▲▼

CHAN

Global

▼

When set to **CC Relative**, these are the available parameters:

- **Type:** The axis will increment or decrement the CC's current value, depending on this setting. Select one of these options:
 - **Up (Type 1)** or **Up (Type 2):** Moving your finger up along the axis increments the value. Moving it down decrements the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
 - **Down (Type 1)** or **Down (Type 2):** Moving your finger up along the axis decrements the value. Moving it down increments the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
- **CC:** The axis will send its MIDI messages using this CC number.
- **Chan:** The axis will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

X-AXIS	
	MIDI NOTE CC ABSOLUTE CC RELATIVE RPN/NRPN OTHER
TYPE	RPN Coarse ▼
MSB	20 ▲▼
LSB	2 ▲▼
CHAN	Global ▼

When set to **RPN/NRPN**, these are the available parameters:

- Type:** The axis will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - RPN Coarse** or **RPN Fine:** Moving your finger along the axis adjusts the RPN coarsely or finely, respectively.
 - NRPN Coarse** or **NRPN Fine:** Moving your finger along the axis adjusts the NRPN coarsely or finely, respectively.
- MSB:** The axis will send this Most Significant Byte value when you move your finger along it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- LSB:** The axis will send this Least Significant Byte value when you move your finger along it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- Chan:** The axis will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

X-AXIS

MIDI

NOTE

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Pitch Bend Sensitivity(RPN)

▼

MIN

0

▲▼

MAX

127

▲▼

CHAN

Global

▼

When set to **Other**, these are the available parameters:

- **Type:** The axis will adjust this parameter when you move it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), or **Pitch Bend**.
- **Min:** The axis's minimum position will correspond with this value. You can reverse the axis's polarity by making this value larger than the **Max** value.
- **Max:** The axis's maximum position will correspond with this value. You can reverse the axis's polarity by making this value smaller than the **Min** value.
- **Chan:** The axis will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Note

X-AXIS

MIDI
NOTE

TYPE	8 Notes	▼	FIRST	60 C (3)	⬆	NOTE 5	67 G (3)	⬆
SCALE	Major	▼	NOTE 2	62 D (3)	⬆	NOTE 6	69 A (3)	⬆
			NOTE 3	64 E (3)	⬆	NOTE 7	71 B (3)	⬆
			NOTE 4	65 F (3)	⬆	LAST	72 C (4)	⬆



When an axis of the **X-Y pad** is in MIDI Note Mode, you can move your finger along it to send a range of MIDI notes.

These are the available parameters:

- **Type:** The length of the entire axis will be divided into this many segments of equal size: **3–8 Notes** or a range of notes that you select.
- **First:** The axis's minimum position will correspond with this MIDI note. If **Type** is set to **Range**, you can reverse the axis's polarity by making this value larger than the **Max** value.
- **Last:** The axis's maximum position will correspond with this MIDI note. If **Type** is set to **Range**, you can reverse the axis's polarity by making this value smaller than the **Min** value.
- **Note 2–7:** These 1–6 additional fields let you assign notes between the first and last notes.
- **Scale:** When using all 3–8 notes, use this menu to select a scale; all 3–8 notes will then be automatically set to ascending note values of the selected scale. You can shift the entire scale up or down by changing its root note (**First**). Select **Off** to disable this feature and select the notes manually.

Sustain Pedal

Click the sustain pedal (just under the encoders) to set the MIDI assignments for the **sustain pedal** on your Code 25. You can assign the parameters for the sustain pedal in MIDI Mode only.



Mode: Click this menu and select one of the following options. The parameters below will depend on your selection.

- **Note:** The pedal will send MIDI note messages.
- **MMC:** The pedal will send MMC (MIDI Machine Control) messages. MMC is a transport control protocol that is used to remotely control some recording hardware and DAWs.
- **Program:** The pedal will send a combined program number, Bank LSB, and Bank MSB number. This can be useful for selecting a preset from a specific bank of a virtual instrument or synthesizer (the instrument or synthesizer must support these messages).
- **Program Inc/Dec:** The pedal will increment/decrement the program number by **1** each time you press it. After it reaches its highest or lowest program, it will “wrap around” and start again at its lowest or highest program, respectively. In other words, pressing the pedal causes the value to cycle through its entire range by increments of 1.
- **CC Absolute:** The pedal will send a CC message with one value when you press it to turn it on and another value when you press it to turn it off. The values will alternate with each press.
- **CC Inc/Dec:** The pedal will increment/decrement a MIDI CC value by **1** each time you press it. After it reaches its highest or lowest value, it will “wrap around” and start again at its lowest or highest value, respectively. In other words, pressing the pedal causes the value to cycle through its entire range by increments of 1.

- **RPN/NRPN:** The pedal will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The pedal will send a message for another type of command.

SUSTAIN		MIDI						
	NOTE	MMC	PROGRAM	PROGRAM INC/DEC	CC ABSOLUTE	CC INC/DEC	RPN/NRPN	OTHER
NOTE	65 F(4)							
CHAN	Global							
ON	127							
OFF	0							

When set to **Note**, these are the available parameters:

- **Note:** The pedal will send this MIDI note number when you press it.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).
- **Latch:** When Latch is enabled, the pedal will send one value when pressed and a different value when pressed a second time, alternating between the two values with each press (“latching” or “toggle” behavior). When Latch is disabled, the pedal will send one value when pressed and one value when released (“momentary” behavior).
- **On:** The pedal will send the MIDI note number with this velocity when you press it to turn it on.
- **Off:** The pedal will send the MIDI note number with this velocity when you press it to turn it off. This value will usually be **0** (to turn the note off).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

MMC

Stop

▼

CHAN

Global

▼

When set to **MMC**, these are the available parameters:

- **MMC:** The pedal will send this MMC message when you press it. Select **Stop**, **Play**, **Deferred Play**, **Fast-Forward**, **Rewind**, **Record Strobe** (Punch In), **Record Exit** (Punch Out), **Record Pause**, **Pause**, **Eject**, **Chase**, or **MMC Reset**.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

PROGRAM

20

▲▼

MSB

30

▲▼

LSB

40

▲▼

CHAN

Global

▼

When set to **Program**, these are the available parameters:

- **Program:** The pedal will send this program number when you press it.
- **MSB:** The pedal will send this Bank MSB (Most Significant Byte) number when you press it.
- **LSB:** The pedal will send this Bank LSB (Least Significant Byte) number when you press it.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

TYPE

Increment

▼

MIN

0

▲▼

MAX

60

▲▼

CHAN

Global

▼

When set to **Program Inc/Dec**, these are the available parameters:

- **Type:** The pedal will send the next (**Increment**) or previous (**Decrement**) program number in the range of programs when you press it.
- **Min:** The lowest program in the range of programs will correspond with this value.
- **Max:** The highest program in the range of programs will correspond with this value.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

CC	0 Bank Select	⬆️⬆️
DOWN	127	⬆️⬆️
UP	0	⬆️⬆️
CHAN	Global	✓

When set to **CC Absolute**, these are the available parameters:

- **CC:** The pedal will send its MIDI messages using this CC number.
- **Down:** The pedal will send the MIDI CC number with this value when you press it.
- **Up:** The pedal will send the MIDI CC number with this value when you release it.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

TYPE

Increment

▼

CC

0 Bank Select

▲

▼

MIN

0

▲

▼

MAX

61

▲

▼

CHAN

Global

▼

When set to **CC Inc/Dec**, these are the available parameters:

- **Type:** The pedal will send the next (**Increment**) or previous (**Decrement**) value number in the range of values when you press it.
- **CC:** The pedal will send its MIDI messages using this CC number.
- **Min:** The lowest value in the range of values will correspond with this value.
- **Max:** The highest value in the range of values will correspond with this value.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

TYPE

RPN Coarse

▼

CHAN

Global

▼

MSB

20

▲▼

LSB

30

▲▼

VALUE

40

▲▼

When set to **RPN/NRPN**, these are the available parameters:

- Type:** The pedal will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - RPN Coarse** or **RPN Fine:** Pressing the pedal adjusts the RPN coarsely or finely, respectively.
 - NRPN Coarse** or **NRPN Fine:** Pressing the pedal adjusts the NRPN coarsely or finely, respectively.
- MSB:** The pedal will send this Most Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- LSB:** The pedal will send this Least Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- Value:** The pedal will send this value with the RPN or NRPN when you press it.
- Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

SUSTAIN

MIDI

NOTE

MMC

PROGRAM

PROGRAM INC/DEC

CC ABSOLUTE

CC INC/DEC

RPN/NRPN

OTHER

TYPE

Pitch Bend Sensitivity(RPN)

VALUE

127

CHAN


Global

When set to **Other**, these are the available parameters:

- **Type:** The pedal will send a value for this parameter when you press it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), **Pitch Bend**, **Reverb Type** (SysEx), **Reverb Time** (SysEx), or **Chorus Type** (SysEx).
- **Value:** The pedal will send this value for the parameter when you press it.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Volume Pedal

Click the volume pedal (in the lower-right corner) to set the MIDI assignments for the **volume pedal** on your Code 25. You can assign the parameters for the volume pedal in MIDI Mode only.



Mode: Click this menu and select one of the following options. The parameters below will depend on your selection.

- **CC Absolute:** The pedal will send CC messages based on its current physical position.
- **CC Relative:** The pedal will send CC messages to increment or decrement the current value.
- **RPN/NRPN:** The pedal will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**).
- **Other:** The pedal will send a message for another type of command.

VOLUME

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

CC	7	Channel Volume	↕
MIN	0		↕
MAX	127		↕
CHAN	Global		↕

When set to **CC Absolute**, these are the available parameters:

- **CC:** The pedal will send its MIDI messages using this CC number.
- **Min:** The pedal's minimum position will correspond with this value. You can reverse the pedal's polarity by making this value larger than the **Max** value.
- **Max:** The pedal's maximum position will correspond with this value. You can reverse the pedal's polarity by making this value smaller than the **Min** value.
- **Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

VOLUME

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Up (Type 1)

▼

CC

7 Channel Volume

▲▼

CHAN

Global

▼

When set to **CC Relative**, these are the available parameters:

- **Type:** The pedal will increment or decrement the CC's current value, depending on this setting. Select one of these options:
 - **Up (Type 1) or Up (Type 2):** Moving the pedal up increments the value. Moving it down decrements the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
 - **Down (Type 1) or Down (Type 2):** Moving the pedal up decrements the value. Moving it down increments the value. If your software does not respond to the **(Type 1)** setting, use the **(Type 2)** setting—or vice versa.
- **CC:** The fader will send its MIDI messages using this CC number.
- **Chan:** The fader will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

VOLUME

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

RPN Coarse

▼

MSB

7

▲▼

LSB

27

▲▼

CHAN

Global

▼

When set to **RPN/NRPN**, these are the available parameters:

- Type:** The pedal will send a registered parameter number (**RPN**) or non-registered parameter number (**NRPN**), depending on this setting. Select one of these options:
 - RPN Coarse** or **RPN Fine:** Moving the pedal adjusts the RPN coarsely or finely, respectively.
 - NRPN Coarse** or **NRPN Fine:** Moving the pedal adjusts the NRPN coarsely or finely, respectively.
- MSB:** The pedal will send this Most Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN MSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN MSB.
- LSB:** The pedal will send this Least Significant Byte value when you press it. If **Type** is set to **RPN Coarse** or **RPN Fine**, it will send the RPN LSB. If **Type** is set to **NRPN Coarse** or **NRPN Fine**, it will send the NRPN LSB.
- Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

VOLUME

MIDI

CC ABSOLUTE

CC RELATIVE

RPN/NRPN

OTHER

TYPE

Pitch Bend Sensitivity(RPN)

MIN

0

MAX

127

CHAN

Global

When set to **Other**, these are the available parameters:

- Type:** The pedal will adjust this parameter when you move it. Select one of these options: **Pitch Bend Sensitivity** (RPN), **Fine Tune** (RPN), **Coarse Tune** (RPN), **Channel Pressure**, **Master Volume** (SysEx), **Master Pan** (SysEx), **Coarse Tune** (SysEx), **Fine Tune** (SysEx), **Chorus Mod. Rate** (SysEx), **Chorus Mod. Depth** (SysEx), **Feedback** (SysEx), **Send to Reverb** (SysEx), or **Pitch Bend**.
- Min:** The pedal's minimum position will correspond with this value. You can reverse the pedal's polarity by making this value larger than the **Max** value.
- Max:** The pedal's maximum position will correspond with this value. You can reverse the pedal's polarity by making this value smaller than the **Min** value.
- Chan:** The pedal will send its messages over this channel. Select the global channel (**Global**), a specific channel (**Channel 1–16**), or a zone (**Zone 1–4**).

Global Settings

The Global Settings affect the overall operation of your Code 25 keyboard, regardless of the current preset.

To open Global Settings, click **File** and then click **Global Settings**.

To send the global settings to your connected Code 25, click **Send Settings**.

To retrieve the global settings from your connected Code 25, click **Get Settings**.

GLOBAL SETTINGS

GLOBAL CHANNEL	Channel 1	<
XY PAD CURVE	F1	<
MACKIE CONTROL / HUI	Mackie Control	<
KEY OCTAVE	0	< >
KEY TRANSPOSE	0	< >
KEY CURVE	C1	<
PAD OCTAVE	0	< >
PAD TRANSPOSE	0	< >
PAD CURVE	C1	<
ENCODER CURVE	Off	<
PROGRAM	0	< >
MSB	0	< >
LSB	0	< >

Get Settings

Send Settings

These are the available settings:

- **Channel:** This menu lets you set the global channel (**Channel 1–16**). Any other controls or zones whose **Chan** settings are set to **Global** will send their messages using this channel.
- **XY Pad Curve:** This field determines the velocities of the notes the **X-Y pad** sends as you move your finger across it. This setting affects the X-Y pad in MIDI Note Mode only. See [Appendix > Velocity Curves > X-Y Pad](#) for descriptions of the different settings.
- **Mackie Control/HUI:** This menu determines whether the **faders**, **buttons**, and **encoders** can be set to Mackie Control Mode (**Mackie Control**) or HUI Mode (**HUI**).

When set to **Mackie Control**, you can use the **Fader Mode**, **Button Mode**, and/or **Encoder Mode** buttons to set the **faders**, **buttons**, and/or **encoders** Mackie Control Mode.

When set to **HUI**, you can use the **Fader Mode**, **Button Mode**, and/or **Encoder Mode** buttons to set the **faders**, **buttons**, and/or **encoders** HUI Mode.

- Key Octave:** This field determines the current octave shift of the entire **keybed** (-3 to 4).
Note: The keyboard's overall octave and transposition are independent from the zones' octaves and transpositions, but all of these affect the note a key sends out.
- Key Transpose:** This field determines the current transposition of the entire **keybed** (-12 to 12).
Note: The keyboard's overall octave and transposition are independent from the zones' octaves and transpositions, but all of these affect the note a key sends out.
- Key Curve:** This field determines the velocity sensitivity of the **keybed**—the amount of force required to generate a note with a specific velocity. See [Appendix > Velocity Curves > Keybed](#) for descriptions of the different settings.
- Pad Octave:** This field determines the current octave shift of the **pads** (-5 to 5).
- Pad Transpose:** This field determines the current transposition of the **pads** (-12 to 12).
- Pad Curve:** This field determines the velocity sensitivity of the **pads**—the amount of force required to generate a note with a specific velocity. See [Appendix > Velocity Curves > Pads](#) for descriptions of the different settings.
- Encoder Curve:** This field determines the rate of acceleration as you turn an encoder. See [Appendix > Velocity Curves > Encoders](#) for descriptions of the different settings.
- Program:** This field determines the number of the program change message that will be sent when you click **Send Settings**.
- MSB:** This field determines the number of the Bank MSB (Most Significant Byte) message that will be sent when you click **Send Settings**.
Note: A Bank LSB or Bank MSB number may not have any effect until you send a program change message after it.
- LSB:** This field determines the number of the Bank LSB (Least Significant Byte) message that will be sent when you click **Send Settings**.
Note: A Bank LSB or Bank MSB number may not have any effect until you send a program change message after it.

Software Menus

File

- Send Preset** Select this to export the current settings from the Code 25 Editor to your connected Code 25 keyboard. Alternatively, press **Ctrl+Shift+S** (Windows) or **Control+Shift+S** (Mac OS X).
- Retrieve Preset** Select this to import the current settings from your connected Code 25 keyboard into the Code 25 Editor. Alternatively, press **Ctrl+Shift+R** (Windows) or **Control+Shift+R** (Mac OS X).
- Load Preset** Select this to locate and load a preset file (**.Code25**) on your computer to the Code 25 Editor. Alternatively, press **Ctrl+O** (Windows) or **Control+O** (Mac OS X).
- Save Preset** Select this to save the Code 25 Editor's current settings to your computer as a preset file (**.Code25**). Alternatively, press **Ctrl+S** (Windows) or **Control+S** (Mac OS X).
- Global Settings** Select this to open the Global Settings window. See [Global Settings](#) to learn about this.
- Exit** Select this to close the Code 25 Editor.

Mac OS X users: This option is in the Code 25 Editor menu.

Help

- Open User Guide** Select this to open this *User Guide*.
- About Code 25 Preset Editor** Select this to view information about this version of the Code 25 Preset Editor.

Mac OS X users: This option is in the **Code 25 Preset Editor** menu.

Appendix

Velocity Curves

Encoders

To select one of these curves, use the **Encoder Curve** field in the **Global Settings**. See the [Global Settings](#) chapter to learn about this.

Curve Number	Code 25 Display	Description
0	ECrVOF	Turning the encoder will always send a value change of one step in either direction regardless of how quickly/slowly you turn it.
1	ECrVC1	This is a slow acceleration curve, useful for making fine adjustments.
2	ECrVC2	This is a medium acceleration curve (the default).
3	ECrVC3	This is a quick acceleration curve, useful for making coarse adjustments with broad “sweeps.”

Keybed

To select one of these curves, use the **Key Curve** field in the **Global Settings**. See the [Global Settings](#) chapter to learn about this.

Curve Number	Code 25 Display	Description
1	VCrVC1	This is a low-sensitivity setting, useful for playing notes with mostly low velocities.
2	VCrVC2	This is a medium-sensitivity setting (the default), useful for playing with an average amount of force.
3	VCrVC3	This is a high-sensitivity setting, useful for playing notes with mostly high velocities.
4	VCrVC4	This is a linear curve. The velocity of the note will be proportional to the amount of force.
5	VCrVF1	All notes will have a fixed velocity of 64 .
6	VCrVF2	All notes will have a fixed velocity of 100 .
7	VCrVF3	All notes will have a fixed velocity of 127 .

Pads

To select one of these curves, use the **Pad Curve** field in the **Global Settings**. See the [Global Settings](#) chapter to learn about this.

Curve Number	Code 25 Display	Description
1	PCrVC1	This is a low-sensitivity setting, useful for playing notes with mostly low velocities.
2	PCrVC2	This is a medium-sensitivity setting (the default), useful for playing with an average amount of force.
3	PCrVC3	This is a high-sensitivity setting, useful for playing notes with mostly high velocities.
4	PCrVC4	This is a linear curve. The velocity of the note will be proportional to the amount of force.
5	PCrVF1	All notes will have a fixed velocity of 64 .
6	PCrVF2	All notes will have a fixed velocity of 100 .
7	PCrVF3	All notes will have a fixed velocity of 127 .
8	PCrVS2	All notes will have a velocity of 64 or 127 , depending on the amount of force.
9	PCrVS3	All notes will have a velocity of 64 , 100 , or 127 , depending on the amount of force.
10	PCrVS4	All notes will have a velocity of 32 , 64 , 100 , or 127 , depending on the amount of force.

X-Y Pad

To select one of these curves, use the **XY Pad Curve** field in the **Global Settings**. See the [Global Settings](#) chapter to learn about this.

Curve Number	Code 25 Display	Description
1	TCrVF1	All notes will have a fixed velocity of 64 (the default).
2	TCrVF2	All notes will have a fixed velocity of 100 .
3	TCrVF3	All notes will have a fixed velocity of 127 .
4	TCrVS2	The velocities of the notes will between 64 and 127 .
5	TCrVS3	Every third note will have a velocity of 127 . All other notes will have a velocity of 64 .
6	TCrVS4	The velocities of the notes will between 100 and 127 .
7	TCrVS5	Every third note will have a velocity of 127 . All other notes will have a velocity of 100 .
8	TCrVS6	Each axis represents the range of velocities from 64 to 127 . A note generated at the axis's minimum point will have a velocity of 64 . A note generated at the axis's maximum point will have a velocity of 127 .
9	TCrVS7	Each axis represents the range of velocities from 100 to 127 . A note generated at the axis's minimum point will have a velocity of 100 . A note generated at the axis's maximum point will have a velocity of 127 .
10	TCrVS8	Each axis represents the range of velocities from 1 to 127 . A note generated at the axis's minimum point will have a velocity of 1. A note generated at the axis's maximum point will have a velocity of 127 .

Trademarks & Licenses

M-Audio is a trademark of inMusic Brands, Inc., registered in the U.S. and other countries.

Mac and OS X are trademarks of Apple Inc., registered in the U.S. and other countries.

Mackie Control and HUI are trademarks or registered trademarks of LOUD Technologies Inc.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

All other product names, company names, trademarks, or trade names are those of their respective owners.

m-audio.com