

# FLEXUS FX100

## AUDIO ANALYZER

# QUICK GUIDE



### PACKAGE LIST

- FLEXUS FX100 Audio Analyzer
- Mains cable
- USB cable
- FLEXUS CD (PC software and product information)
- Calibration certificate
- This quick guide



### OPERATING CONDITIONS & SAFETY ADVICE

- Required mains power: 90 - 264 VAC / 47 - 63Hz.
- Maximum voltage at analog inputs: 200Vp.
- Do not apply AC voltages to analog outputs.
- Environmental conditions
  - Operating: 5°C to 45°C / 90% RH non-condensing.
  - Storage: -20°C to 80°C / 90% RH non-condensing.
- You may stack up to four FLEXUS units.
- Keep front panel ventilation inlet holes open.
- For detailed specifications see [www.nti-audio.com/flexus](http://www.nti-audio.com/flexus)





### MAINTENANCE

- There are no serviceable parts inside.
- Clean surface with a dry cleaning cloth. You may use a mild cleaning agent if required.



# INTRODUCTION

Make yourself familiar with the connections, controls and elements of your FLEXUS audio analyzer.





## START OF OPERATION

1. Unpack items.
2. Install software.
  - Insert FLEXUS CD into the CD drive of your PC.
  - Open CD drive folder and double-click on setup.exe.
  - Follow installation instructions.
3. Connect FLEXUS to mains power.
4. Connect FLEXUS and PC with USB cable, using the USB-B connector.
5. Launch FX-Control. 
6. FX-Control will start with a default measurement project
7. For further information on how to operate FX-Control, please use the online help via the "F1" key.



## HOW TO ...


### Operate the FX 100 front panel



The FX100 can be operated with the Push&Turn wheel on the front panel. It allows navigating through a menu system.

- By turning the wheel, the highlighted active item can be changed.
- By pressing on a active item, the functionality gets active.

### Perform a firmware upgrade




If there is a new firmware available, FX-Control will notify you upon startup.

- Confirm and download the \*fxu file to the root folder of an USB memory stick.
- Plug the USB memory stick into one of the USB Type-A connectors of your FLEXUS unit.
- Select the FLEXUS menu **SYSTEM** → **=VER** → **FW-UPDATE**
- Select the stored fxu file from the list.
- The firmware upgrade will proceed automatically. This may take up to a few minutes. Do not switch off the unit during the firmware upgrade process.




## Set the FLEXUS date and time



- Select the FLEXUS menu **SYSTEM** → **=TIME**
- Set the correct date and time.

## Configure the headphone output



Content Source Volume

### Content:

- MONITOR (the unfiltered analyzer input signal).
- PURESOUND (the bandlimited PureSound analysis input filter).

### Source:

- The analyzer channel number routed to the headphone output.

### Volume:

- Controls the volume from 0% to 100%

## Perform a system check

- Navigate through the FLEXUS menus to **SYSTEM** → **=TST**
- The system will perform a few basic tests and return **PASSED** or **FAILED**

## Determine the calibration due date

- Navigate through the FLEXUS menus to **SYSTEM** → **?CAL**
- The system will display the last calibration date, and the next calibration due date.

## Get further information and support

- Register your FX100 under <http://my.nti-audio.com> for product news, firmware and software updates.
- Consult the FX100 user manual on the FLEXUS CD.
- Contact your local NTi Audio partner for technical support.

### NTi Audio AG

Im alten Riet 102  
9494 Schaan  
Liechtenstein / Europe  
Phone: +423 239 60 60  
Fax: +423 239 60 89  
info@nti-audio.com

### NTI Americas Inc.

P.O. Box 231027  
Tigard, Oregon  
97281, United States  
Phone: +1 503 684 7050  
Fax: +1 503 684 7051  
americas@nti-audio.com

### NTI China

Room 722, 7F, Building 6-3A,  
No 1388, Bin He Rd.  
215000 Suzhou  
Phone: +86 512 6802 0075  
Fax: +86 512 6802 0097  
china@nti-audio.com

### NTI Japan

Ryogokusakamoto Bldg.  
1-8-4 Ryogoku  
130-0026 Sumida-ku, Tokyo  
Phone: +81 3 3634 6110  
Fax: +81 3 3634 6160  
japan@nti-audio.com

