

LIVE TO PLAY LIVE®

MC401 BOOST/ LINE DRIVER

JIMDUNLOP.COM

92503004776revD

MC401 BOOST/LINE DRIVER


DESCRIPTION

 Boost function with knob adjustment from 0 to +20dB of clean uncolored boost True bypass


POWER The MXR/CAE Boost/Line Driver is powered by one 9 volt battery (remove bottom plate to install), a 9 volt AC Adapter such as the Dunlop ECB003/ECB003EU or a powersupply such as the DC Brick[™].

CONTROLS





- 2 AC adapter input
- Footswitch toggles effect on/bypass (ice blue LED indicates on)



DIRECTIONS

- Run a cable from your guitar to the Boost/Line Driver's Input jack and run another cable from the Boost/Linedriver's Output jack to your amplifier. Start with the Boost knob at
- 0dB. Rotate the knob clockwise to increase boost level, up to +20dB.

nput Impedance	1 kΩ
Dutput Impedance	150 Ω
Nominal Input	-22 dBV
Dutput Level	-22 dBV
Boost Gain Range	20 dB

SPECIFICATIONS

(

dBV dBV 20 dB Noise Floor* >95 dB Bypass True Hardwire Current Draw 1.5 mA 9 volts DC Power Supply *A-weighted, V_{ref}=1_{Vrms}

