



XS WIRELESS 1

Quick Guide | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kısa Kılavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서

In the box	Vocal Sets		Instrument Sets		Lavalier Set	Headmic Set
	XSW 1-825	XSW 1-835	XSW 1-CI1	XSW 1-908	XSW 1-ME2	XSW 1-ME3
XS WIRELESS 1						
EM-XSW 1 	•	•	•	•	•	•
NT 12-5CW 	•	•	•	•	•	•
SKM 825-XSW 	•	•	•	•	•	•
MZQ 1 	•	•	•	•	•	•
SKM 835-XSW 	•	•	•	•	•	•
SK-XSW 	•	•	•	•	•	•
e 908T 	•	•	•	•	•	•
ME 2-2 	•	•	•	•	•	•
ME 3-II 	•	•	•	•	•	•
CI 1-N 	•	•	•	•	•	•
2 x AA LR6 1.5 V 	•	•	•	•	•	•

Battery

-
-
-

Low Battery

~ 10 h	
~ 7 h	
~ 3 h	
Low Batt	

Setup

On/off

Display

Volume

Mute

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Germany, Publ. 02/17, 571312/A02

SENNHEISER

Change frequency

Automatically/Scan

- Off
- 3s
- 23
- 23
- 23

Manually

- Bank Channel
- 13
- 23
- 23
- 23
- 23

Sync

- hold
- 1x
- OR

Sensitivity

- 0 dB
- 10 dB
- 20 dB
- 30 dB

Level

OR

Multichannel

Bank 1...8
Ch. 0...9

Bank	CH.	Bank	CH.	Bank	CH.	Bank	CH.	
2	3	2	4	2	5	2	6	✓
1	1	1	2	1	3	1	8	✓
2	3	1	3	4	7	8	9	✗
2	3	2	3	2	3	2	3	✗

max. 10 ch.

ME 2-2

25 cm (10")

ME 3-II

2...3 cm (1")

Min. distance

> 5 m (16'5")

SKM

Guitar pickup

> 20 cm (8")

Squelch

min. SQ

max. SQ