


# Operation Manual



## Mini Amplifier I-5G (For Guitar)



### ★ CONTROL FUNCTIONS ★

- POWER ..... Turns amplifier ON & OFF.
- GAIN ..... Setting from zero to full power.
- OVER DRIVE ..... This is the OVER DRIVE switch.
- VOLUME ..... Control volume from zero to full.
- TONE ..... Bass to treble tone control.
- INPUT ..... Power on and connection for instrument.
- Mp3 IN ..... Connect the MP3 and other external source equipment.
- PHONES ..... Output for stereo headphones. Automatically disconnects the internal speaker.
- DC JACK ..... Requires DC9V adaptor 500mA(min.) not supplied.

### ★ SPEIFICATIONS ★

- OUTPUT POWER ..... 5 Watt
- SPEAKER ..... 5.0 inch, 4 ohm
- DIMENSIONS ..... W230mm x H185mm x D120mm
- WEIGHT ..... 1.9Kg(Including Battery)
- BATTERY ..... 9V (6F22 Type x 2)

### WARNING --

**Amplifier fails to function, please contact your local distributor.  
Under no circumstances remove the back panel of the amplifier while it is  
Connected to main supply.**