


Level the mount and mark.


Drill the mounting holes.

Fix the plate to the wall.


Attach the mounting rails to screen.
- Ensure that each rail mounting slot is facing down.
- Use the selected screws and washers to mount the rail to screen.





Tightly secure the mounting screws.



Mount screen to the wall.



Secure the safety lock.



SONOROUS®
SOUND AND VISION IN STYLE