KRAMER





KT-1010SC / KT-1010SCRB Quick Start Guide

This guide helps you install and use your KT-1010SC / KT-1010SCRB for the first time.

Go to www.kramerav.com/downloads/KT-1010SC to download the latest user manual and check if firmware upgrades are available.

 $\mathbf{\mathbf{V}}$

Step 1: Check what's in the box

- \mathbf{V} KT-1010SC KronoMeet Touch Panel or KT-1010SCRB KronoMeet Touch Panel (Reduced Bandwidth)
- \mathbf{V} On-wall mount bracket 12V AC/DC power adapter
- Quick start guide Panel mount bracket
 - $\mathbf{\mathbf{V}}$
- 2 LED side bars
- Installation screws

Step 2: Get to know your KT-1010SC / KT-1010SCRB



#	Feature	Function
1	Volume Buttons (+/-)	Press to increase/decrease KT-1010SC speaker volume.
2	Up/Down ($ riangle/ abla$) Keys	Press to scroll through the menu options.
3	Exit Button	Press to exit the menu.
4	SD Card Slot and Cover	Add an external memory card.
5	Power LED	Power on indication. Orange when loading, then turns green.
6	2 LED Side-Bar Module Slots	Connect to LED side bars to indicate the room status.
7	2 Speakers	To output the sound.
8	4 VESA Mounting Screw Holes (75x75mm)	Connect to a VESA kit to mount on a wall.
9	12V DC Input with Cable Security Lock	Connect to the AC/DC adapter and to the mains.
10	Add-on USB Module Slot	For future use.
11	Ethernet PoE RJ-45 Connector	Connect to a PC via a LAN.
12	USB Type A Port	Connect to USB peripherals (such as a keyboard, printer, etc.).
13	Micro USB Port	Connect to USB peripherals (such as a keyboard, printer, etc.).
14	2 Control I/O Ports	For future use.
15	Power ON/OFF Switch	Press to turn power on or off.

KT-1010SC, KT-1010SCRB Quick Start





P/N: 2900-301336QS

Step 3: Mount KT-1010SC / KT-1010SCRB

Before mounting **KT-1010SC** on a wall, connect the two LED side bars to the LED module slots on both sides of the device and tighten to the rear side with the 2 screws (included with the side bars).

To mount KT-1010SC on a wall using the VESA kit:

- 1. Secure the on-wall mount to the wall using the installation screws.
- Attach the panel mount bracket to the VESA mounting holes on the rear side of the KT-1010SC.
- Slide the panel mount bracket to the onwall bracket already mounted on the wall.





- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.
- Reliable earthing of rack-mounted equipment should be maintained.

Step 4: Connect power

Connect the Ethernet port to a PoE Ethernet port, using a PoE-compliant Ethernet cable. Alternatively, or in addition to PoE powering, connect the power adapter to the 12V AC/DC power socket and to the main electricity.



- Safety Instructions (See <u>www.kramerav.com</u> for updated safety information). Caution:
- There are no operator serviceable parts inside the unit
- Warning:Use only the power cord that is supplied with the unit.
- Disconnect the power cord that is supplied with the diff.
 Disconnect the power and unplug the unit from the wall before installing.

Step 5: Operate KT-1010SC / KT-1010SCRB

To operate KT-1010SC for the first time:

- 1. Turn the power switch on the rear of the touch panel to ON. Wait for Kramer KronoMeet log-in page to load.
- 2. Press Exit (3) on the rear of the panel to exit the KronoMeet app.
- 3. Enter the default password (Kramer) and proceed to the Home Screen.
- 4. Make sure the device is connected to the Internet.
- (i) If the device is connected via Wi-Fi:
 - Press Exit (3) and enter the default password (Kramer).
 - Click Home Page>Settings>Wi-Fi and choose your SSID Network.
 - Reboot your device.
- Check the Google Play Store to ensure that KT-1010SC is running the latest version of KronoMeet App.

To Launch the KronoMeet App and activate the KronoMeet panel:

- 1. Enter your KronoMeet Activation Code for this meeting space from the KronoMeet dashboard
- 2. Click Activate on the panel.







