

# 快速使用指南

## 1 连接方法


**耳机接口：**连接耳机（带麦或不带麦的耳机都可以兼容）

**手机接口：**与手机 $\Phi 3.5\text{mm}$ 接口连接，如手机没有 $\Phi 3.5\text{mm}$ 接口，需配合OTG转接头使用

**连麦接口：**通过标配的音频线与第2支PH 200的手机接口连接，实现双人合唱

**伴奏接口：**通过标配的音频线连接外部音源设备，方便直播时播放伴奏

**USB接口：**通过Micro USB数据线给麦克风充电或实现OTG功能



## 2 功能使用方法

**电源指示灯**

**内放指示灯**

**电声基调：**在音效切换到“电音”效果模式后，点按切换电音基调，根据演唱歌曲的基调进行选择

**开关：**长按2秒开关机，点按开启内放功能（内放功能解释详见说明书）

**音量+/-：**调节麦克风音量，根据个人对音量大小的适应情况适当调节

**音效：**点按切换8种美声效果，同时有相应的语音提示



## 3 其它

**充电：**电源指示灯长亮红灯，表示电量较低，需及时给麦克风充电

**内放：**开机状态下循环点按电源按钮，指示灯长亮绿灯，表示内放开启；指示灯熄灭，表示内放关闭。


# Quick Start Guide

---

## 1 Connection

**Headset connector:** linking with headset (headset with or without mic).

**Mic connector:** linking with the second PH200 mic via standard audio cable for chorus.



**Cell phone connector:** linking with cell phone  $\Phi 3.5\text{mm}$  connector. If the cell phone has no  $\Phi 3.5\text{mm}$  connector, use OTG adapter.

**Accompaniment connector:** linking with external audio equipment via standard audio cable for playing accompaniment.

## 2 Function operation

**Autotune:** when it is switched to autotune mode, press it to switch autotune. Select the autotune according to specific song.

**Switch:** press it for 2 seconds to turn on mic. Press it to turn on mixing function (refer to mixing function section in the manual for details).



**Volume +/-:** adjusting mic volume to a proper level.

**Sound effect:** 8 sound effects for switching, and there are relative sound prompt.

## 3 Others

**Charging:** that the power LED keeps lighting up red means low power supply. Please charge the microphone in time.

**Mixing:** after turning on the mic press the power switch. That LED keeps lighting up green means the mixing function is on, and LED lights off means mixing function is off.