


Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES." These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

Copyright © 2005 BOSS CORPORATION
All rights reserved. No part of this publication may be reproduced in any form without the written permission of BOSS CORPORATION.

Panel Descriptions




- 1. Free Pockets**
Use these for your AC adaptor and other small items.

How to Connect

- * To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.
 - * Once the connections have been completed, turn on power to your various devices in the order specified. By turning on devices in the wrong order, you risk causing malfunction and/or damage to speakers and other devices.
- When powering up:** Turn on the power to your guitar amp last
When powering down: Turn off the power to your guitar amp first

- 1. Connect the BOSS compact effects pedals with the L-L cable.**
* If powering the effects with their own batteries, be sure to disconnect the L-L cable after use to prevent battery drain.



Specifications


Dimensions: 330 (W) x 81 (D) x 300 (H) mm
13 (W) x 3-3/16 (D) x 11-13/16 (H) inches
Weight: 1.2 kg / 2 lbs 11 oz

Features


- Pedal board accommodates three BOSS compact effects pedals.
- Exterior body made of tough, molded resin designed to withstand impact from falls and heavy loads.
- When connected to an AC adaptor (optional PSA Series), the BCB-30 supplies power for up to three BOSS compact effect pedals through the parallel DC cable.

- 2. Pedal Spaces**
Spaces designed especially for holding BOSS compact effect pedals.
- 3. 4P Parallel DC Cable**
When connected to an AC adaptor (optional PSA Series), this cable supplies power for up to three BOSS compact effect pedals.
- * To avoid the risk of damage and/or malfunction, do not connect any adaptor other than the PSA.
 - * If using any effect pedals designed for use with ACA adaptors, you need to make sure that at least one of the effect pedals that you have connected is designed for PSA adaptors.
- 4. L-L Cable**
Use this cable to connect the BOSS compact effects pedals.

- 2. Use the 4P parallel DC cable to connect the AC adapter to the BOSS compact effects as shown in the figure.**
* Check the current consumption of each effects unit and make sure that the combined total does not exceed the PSA adaptor's capacity of 200 mA.




- 3. Connect the effects to the guitar amp and guitar as shown in the figure.**



Accessories: 4P Parallel DC Cable x 1, L-L Cable (130 mm) x 2, Owner's Manual
Option: AC Adaptor (PSA series)

Instructions for Removing the Cover

1. Lift the cover to the position shown in the figure.
2. Push the cover in the direction indicated by the arrow.



USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
⊘	The ⊘ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
Ⓢ	The Ⓢ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.
- Do not open or perform any internal modifications on the unit.
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information."



⚠ WARNING

- Make sure you always have the unit placed so it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces.
- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.



- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.



- Protect the unit from strong impact. (Do not drop it!)



⚠ CAUTION

- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.



- Never climb on top of, nor place heavy objects on the unit.



IMPORTANT NOTES

In addition to the items listed under "USING THE UNIT SAFELY," please read and observe the following:

Placement

- Do not expose the unit to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the unit.

Maintenance

- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- When connecting / disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.



* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.