



NANO CLONE

Full Chorus



Congratulations on your purchase of the Electro Harmonix Nano Clone. The Nano Clone is a compact battery operated Chorus device that features a RATE control allowing you to change the speed of the Chorus.

To produce the Chorus effect, the Nano Clone bends the frequency slightly from the input source and mixes this altered signal with some direct unaffected signal. The combination produces a doubling effect.

- OPERATING INSTRUCTIONS -

Connect your instrument to the INPUT jack. Connect your amplifier to the AMP jack. Please note that whenever a plug is inserted into the INPUT jack, the Nano Clone is ON and it is draining current from the battery.

The RATE knob controls the speed of the chorus effect. Turning the RATE knob clockwise increases the rate of the chorus.

The red LED will light up when the Nano Clone is in effect mode. When in True Bypass mode, the LED will be off. Use the FOOTSWITCH to toggle between effect and True Bypass mode.

- POWER -

Power from the internal 9-volt battery is activated by plugging into the INPUT jack. The input cable should be removed when the unit is not in use to avoid running down the battery. If a battery eliminator is used, the Nano Clone will be powered up as long as a wall-wart is plugged into the wall.

The optional 9V power supply from Electro-Harmonix is US96DC-200BI (same as used by Boss™ & Ibanez™) 9.6 volts/DC 200ma. The barrel connector on the front of the Nano Clone is for the 9-volt battery eliminator capable of delivering 100 mA of current. The inner ring of the 9-volt battery eliminator must be negative, the outer ring positive. The unit's battery may be left in or taken out when the eliminator is in use.

PLEASE NOTE: If the Nano Clone is connected to other effects pedals it will not work with the same battery eliminator that is daisy chained to the other pedals. The

Nano Clone works off of a negative power supply and therefore either needs its own battery eliminator or should be run off the battery. If you do daisy chain your battery eliminator to the Nano Clone, all of the pedals on that daisy chain will power down, including the Nano Clone. If this happens, immediately remove the Nano Clone and give the Nano Clone its own power supply, otherwise you risk damaging the Nano Clone, your other pedals or the battery eliminator. Do not daisy chain the battery eliminator for the Nano Clone with any other Electro-Harmonix pedals except for the EH Muff Overdrive pedal.

To change the 9-volt battery, you must remove the 4 screws on the bottom of the Nano Clone. Once the screws are removed, you can take off the bottom plate and change the battery. Please do not touch the circuit board while the bottom plate is off or you risk damaging a component.

The input impedance presented at the Input Jack is 300 kohms. The output impedance at the Output Jack is 600 ohms.

- WARRANTY INFORMATION -

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term.

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a **Return Authorization Number** (RA#) from EHX Customer Service before returning your product. Include with your returned unit: a written description of the problem as well as your name, address, telephone number, e-mail address, and RA#; and a copy of your receipt clearly showing the purchase date.

United States & Canada

EHX CUSTOMER SERVICE
ELECTRO-HARMONIX
c/o NEW SENSOR CORP.
55-01 2ND STREET
LONG ISLAND CITY, NY 11101
Tel: 718-937-8300
Email: info@ehx.com

Europe

JOHN WILLIAMS

ELECTRO-HARMONIX UK
13 CWMDONKIN TERRACE
SWANSEA SA2 0RQ
UNITED KINGDOM
Tel: +44 179 247 3258
Email: electroharmonixuk@virginmedia.com

This warranty gives a purchaser specific legal rights. A purchaser may have even greater rights depending upon the laws of the jurisdiction within which the product was purchased.

To hear demos on all EHX pedals visit us on the web at **www.ehx.com**
Email us at **info@ehx.com**

FCC COMPLIANCE

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- *Reorient or relocate the receiving antenna.*
- *Increase the separation between the equipment and receiver.*
- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- *Consult the dealer or an experienced radio/TV technician for help.*

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.