


MadBoy®

BOSS-12 12" ACTIVE SUBWOOFER



OWNER'S MANUAL

WWW.MADBOY-AUDIO.COM

Introduction

Congratulations on purchasing this subwoofer. To ensure optimum performance please read and retain this manual, then sit back, relax and enjoy!

Please read and retain this manual, it contains useful information that will ensure you get the very best from your new Active Subwoofer.

Note: This model is supplied in two mains voltage ratings. Please refer to product rear panel for rating.

Contents:

Introduction.....	2
Safety Precautions.....	2-4
Subwoofer Controls.....	5
Subwoofer connect.....	6
Getting Started.....	7
Technical Specifications.....	8

Important Safety Precautions

For safety reasons please read the following instructions and the enclosed Important Safety Information carefully before attempting to connect your subwoofer unit to the mains.

Warning:

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

Caution:

Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.



Caution:

To reduce the risk of electric shock, do not remove cover (or back). There are no user-serviceable parts inside. Please refer all servicing to a qualified engineer.

The lightning flash with the arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This product complies with European Low Voltage (73/23/EEC) and Electromagnetic Compatibility (89/336/EEC) Directives when used according to this instruction manual.



Important Safety Precautions

Read Instructions - All the safety and operating instructions should be read before the product is operated.

Retain Instructions - The safety and operating instructions should be retained for future reference.

Heed Warnings - All warnings on the product and the operating instructions should be adhered to.

Follow instructions - All operating and use instructions should be followed.

Cleaning - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Attachments - Do not use attachments not recommended by the product manufacturer as they may cause hazards.

Water and Moisture - Do not use this product near water - for example, near a bath tub, wash bowl or kitchen sink; in a wet basement, or near a swimming pool etc.

Wall or Ceiling Mounting - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

Accessories - Do not place this product on an unstable surface, stand, bracket or table. The product may fall, causing serious injury to child or adult, and serious damage to the product. Use only a surface, stand bracket or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

A product and stand combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the combination to overturn.



Ventilation - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

Power Sources - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization - In some countries this product may be equipped with a polarized alternating-current line plug (a plug having one pin wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug into the outlet, try reversing the plug. If the plug still does not fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Important Safety Precautions

Alternatively, if this product is equipped with a three-wire grounding-type plug, a plug with a third (grounding) pin, it will only fit into a grounding-type power outlet. This is a safety feature. If the plug does not fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

Power-Cord Protection - Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and point where they exit from the product.

Protective Attachment Plug - The product is equipped with an attachment plug having overload protection. This is a safety feature. See Owners' Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.

Lightning - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

Overloading - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

Servicing - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:


- a) When the power-supply cord or plug is damaged.
- b) If liquid has been spilled, or objects have fallen onto the product.
- c) If the product has been exposed to rain or water.
- d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- e) If the product has been dropped or damaged in any way.
- f) When the product exhibits a distinct change in performance - this indicates a need for service.

Replacement Parts - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorised substitutions may result in fire, electric shock, or other hazards.

Safety Checks - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

Heat - The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

Subwoofer Controls



1. Power indicator

Lights when the subwoofer is powered.

2. Standby

If switched to 'ON', the subwoofer remains permanently on as long as the main power switch is on. With the switch in the 'OFF' position the unit will remain in standby mode until a signal is detected at the input. The unit will then automatically switch itself on. It will then automatically return to standby mode if no input signal is present for approximately 15 minutes. The LED positioned on the rear panel indicates whether the unit is on or in standby mode (red for standby and green when on).

3. Line Input

Connect to an amplifier's or receiver's subwoofer out or pre-out jacks. These inputs automatically sum left and right channel information (see fig.1 below).

4. Line out

Connect to another subwoofer's line in jacks. (See fig.2 below).

5. Subwoofer Level (Volume)

Match the subwoofer's output level to your satellite speakers' output (if used).

6. Crossover Frequency

Controls the high frequency cutoff point. Rotated fully clockwise, it cuts high frequencies above 200 Hz. Rotated fully counterclockwise, it cuts high frequencies above 50 Hz.

7. Phase (Polarity) Switch

Inverts the subwoofer's output polarity so you can set it to match the main speakers.

8. Bass

Some input devices like DVD Sub out is with very low output, so you cannot get enough bass, rotate this knob you can get more bass around 50Hz.

9. Power Switch


Turns the subwoofer on and off.

10. High Level Input/High Level Output


If your amplification system does not have a dedicated subwoofer line output, your subwoofer must be connected via the high level terminals on the rear panel. Connection should be made from the speaker terminals on your amplification system to the High Level Input Connections (see fig.3 below).

Subwoofer's connect


To prevent damage to the amplification system, only connect using line level inputs OR high-level inputs:



(Fig.1)



(Fig.2)



(Fig.3)

Getting Started

Connecting via Line Input Connections

If your amplification system has a dedicated subwoofer line output then you should connect this Subwoofer via the Line Input on the rear panel using a good quality phono lead. Note that if your amplification system has a mono subwoofer line out then use the Left/Mono socket on this Subwoofer.

Connecting via High Level Connections

Do not compromise the performance of your system by using inferior quality cables! Gale recommends that high quality cables of 16 gauge or higher be used. Your professional dealer will give you good advice.

Observing polarity is of the utmost importance while connecting your loudspeakers. Ensure that the red (+) terminals on your amplification system are connected to the red (+) on the subwoofer, and black (-) on your amplification system to black (-) on your subwoofer.

Important Note: Always unplug all A.C. powered components before making any loudspeaker or component connections. This will avoid the risk of electric shock or damage to your equipment.

Running In

Your new unit will require a total of approximately 10 hours of normal use to allow the components to settle into their working routine and reach their optimum performance.

Positioning your Subwoofer

The positioning of your subwoofer will affect the quantity and also quality of the lower frequencies of the system. Locating the subwoofer near a wall will increase the bass response of the speaker. If it is placed too near to a corner however, the overall effect may be too 'boomy'. Due to the low frequency modal characteristics of the room, the response will change as it is placed a little closer, or further away from the listening position. Adjusting the rear panel controls (as explained in previous sections) will also affect the sound, so the answer is to experiment and find the position and settings that provide a good balance between low frequency amount and definition across a range of source material.

Taking Care of your Subwoofer

Cabinets should be dusted and lightly polished as required. Do not use solvent based cleaners, as they may damage the cabinet surface. Do not expose the cabinets to strong, direct sunlight, high temperatures, high humidity or allow them to become wet.

Technical Specifications

Model:	BOSS-12
Frequency Response	50Hz-200Hz
Sensitivity	Line in: 500mV (for max output) Hi Level in: 8V (for max output)
Output Power	200 Watts (4 Ohm)
Mains Voltage	220 Volts 50Hz
Power Consumption	240 Watts (4 Ohm)
Drivers	12" Unshielded long throw woofer
Size (H x W x D) mm	380 x 380 x 434
Size (H x W x D) Inches	15 x 15 x 17.1
Gross Weight	24.6kg / 53.4 Lbs